Plant Incalescence Supervision System (PISS)

Emmett Sebastian



Background

Background

- **Overview:** Use a keypad with an MSP430FR2355 to control the temperature of a plant. System information is printed to an LCD controlled by an MSP430FR2310. Heating/Cooling information is displayed on an LED bar. Heating/Cooling done with Peltier device. All microprocessors are networked with I2C.
- **Primary Goal:** Select mode to alter temperature of the plant. Set temperature averaging window to alter sensitivity. Display temperature (both ambient and plant), window size, heating/cooling, seconds active on LCD and LED bar. Control Peltier.
- **System Functionality:** Features keypad input, temperature sensing, LED bar output, LED status, LCD display, and mosfet control. Networked with I2C, programmed in C.
- **Purpose:** Aims to teach keypad, ADC, LED, I2C, LCD, and transistor interfacing for embedded systems. Provides experience with basic feedback control loops.

02

Development Process

		Requirement/specification	Points	Emmett	Sebastian
		Introduction		X	
		Circuit diagram		X	
Development Process		System architecture diagram		X	x
•		High-level flowchart		x	x
01		Professional demo	2	x	х
UI	FLOWCHART	Collect ambient temperature using the LM19	2	x	
	Both:	Collect data every 0.5 s (proof required)		Х	
	— • ···	Collect the plant's temperature using the LM92	6	X	
	Designed main state machine	Collect data every 0.5 s (proof required)		x	
	Tested new hardware	Collect the time spent in the present mode of operation using an I2C RTC		X	
		Collect data every 1 s (proof required)		X	
	F	Produce a moving average of the temperatures	5	X	
	Emmett:	Regardless of the selected mode, the Peltier must be turned off after 5 minutes	2	x	x
	Built flowcharts for Main, I2C, ADC (LM19), LM92, and RTC	The Peltier device can be turned off	2	X	X
		The Peltier device can be configured to heat	2	X	x
	Sebastian:	The Peltier device can be configured to cool		x	x
		The Peltier device can be configured to match the ambient temperature	2	Х	х
	Built flowcharts for LCD and LED bar	LCD displays the mode of operation	2		X
		Display the mode string in the upper-left corner			X
U2	REUSED HARDWARE	Display the ambient temperature	2		X
		Refresh the temperature at least every 2 s			x
	Emmett:	Display the temperature in the top-right corner			х
	Updated ADC for the new system	Display the temperature with a resolution of 0.1 C			x
		Display the plant temperature	2		x
		Refresh the temperature at least every 2 s			x
	Sebastian:	Display the temperature in the bottom-right corner			X
	Updated LED Bar and LCD for the new system	Display the temperature with a resolution of 0.1 C			X
03		Display the window size			X
	I2C	Display the time spent in the current mode of operation	2		x
	Emmett:	Refresh the time at least every 1 s			x
		Display the seconds in the bottom row of the LCD			X
	Rebuilt I2C code to improve reliability and fix addressing issues	Display up to a 3-digit number			X
	Tied new modules into the I2C code	When the system is actively heating, the lights should fill to the right	2	X	x
		When the system is actively cooling, the lights should fill to the left	2	X	х
		When not actively heating or cooling, the lights should be off	2	X	х
		Total	60	30	30

03

Development Documentation

System Transmission Design (STD)

I2C Formatting Change:

i2c_get_received_data returns true/false i2c_get_received_data input is a 3 byte char array address

Data format:

Byte 1: ID byte. Tells you what type of info the following two byes are:

'P': Plant Temperature Data: Whole, Fractional

'I': Ambient Temperature Data: Whole, Fractional

'T': Time Data: Hundreds, Tens/Ones

> 'A': Heat mode Data: 0, 0

'B' : Cool mode Data: 0, 0 'C' : Match mode Data: 0, 0

'D' : Off mode Data: 0, 0

'#': Set window Data: Tens, Ones


"*': Set temperature mode Data: Whole, Fractional

'+' : Temperature increasing Data: 0, 0


'-': Temperature decreasing Data: 0, 0

'=' : Temperature not changing Data: 0, 0


Software Architecture




Circuit Diagram




Controller Main Flowchart



LED BAR Main Flowchart



LCD Main Flowchart





Demo

05

Extra Credit

Extra Credit

- (+1) The user can select the window size using the keypad
- (+0) The Peltier device can be configured to match a temperature entered using the keypad (Don't think we've done this yet)
- (+1) Display a custom character for the ambient temperature
- (+1) Display a custom character for the plant temperature

TOTAL: +6

THANK YOU